

注: 1. 变形缝W 高度按工程设计。
2. 胶条可选不同颜色, 与装饰层相配。

③ DDJF 型				
W	10	25	50	75
ES	10	38	62	87
伸缩量	5	8	12	18

Material	Aluminum	DRAWING	钱穆
Thickness	ASTM 6063 T5	CHECKING	刘明群
Colour	Clear Anodized	APPROVING	刘云雷
Hardness	ASTM 6063 T5	Picture No.	8

Nanjing Meishuo Building Materials Co., Ltd
Expansion Joint

- Clean the garbage and check whether the gap is equally wide and straight.

The concrete's surface is usually not straight and equally wide after pouring. The sides of the gap should be mended to be equally wide and straight and has smooth surface.
- Make level

The elevation of the screed coat's top = depressive level - height of aluminum base + thickness of water barrier, and the width of the screed coat is more than 150mm.
- Make level with high strength of cement mortar. The width is more than 150mm.
- Install the fire barrier. Then snap the ink line on the screed coat to confirm the sidelines of the aluminum base.
- Install the water barrier. The side line of water barrier can't cover the ink line snapped. (Brush the special glue on the surface of the screed coat and the lower surface of the water barrier. After the glue is almost air drying, put water barrier on the screed coat.)

注: 1. 变形缝W 高度按工程设计。
2. 胶条可选不同颜色, 与装饰层相配。

③ DDJF 型				
W	10	25	50	75
ES	10	38	62	87
伸缩量	5	8	12	18

Material	Aluminum	DRAWING	钱穆
Thickness	ASTM 6063 T5	CHECKING	刘明群
Colour	Clear Anodized	APPROVING	刘云雷
Hardness	ASTM 6063 T5	Picture No.	8

Nanjing Meishuo Building Materials Co., Ltd
Expansion Joint

- Install the aluminum base.
- Nail the scree to make sure the base on a straight line. Or the aluminum plate can be mismatched when the centering bar bolt is screwed down,
- Insert the rubber.