

How to Install the Floating Valve in Our Closed Cooling Tower?

A floating valve is included with each of our closed loop tower. Please install it in the spray water tank/basin properly, and ensure it works effectively in making-up the water level automatically during the commissioning of spray water running.

Below is a reference drawing to install the floating valve in a correct way:



Note:

Make-up water must be inleted downward vertically.